

Modify Billing Settings

Entering Configuration mode

To enter into the configuration mode of the device,

Press *99*979023#**

Destination Billing Increment

Each destination can be assign a billing increment. Routes prefixes for different countries must be entered exactly as it shows in the national telecom dial plan.

Example #1: to Dial Canada From China the dial plan is 001 850 591 8315. The route prefix for this plan is 001850.

Example #2: To Dial Colombia from USA the dial plan is 011 573 114 275 385. The route prefix for this country is 011573

If you wish to set up a uniform route plan with destination billing increments for all countries then you should only enter route plans from the following prefixes; 0 , 1, 2, 3, 4, 5, 6, 7, 8, 9.

How to Enter Destination Billing Increment

The format for entering destination billing increment is:

Memory_Address*Prefix*duration#

Where;

Memory_Address = Memory Location to Store Prefix and Destination; Memory location can be stored from **0601** to **0800**.

Prefix = Route Prefix for whom duration is being set in the memory location; This value has a length of between 1 to 8 digits.

Duration = Billing Increments at which calls would be billed; Range of values that can be entered is 0 to 999 seconds.

Example #1: To store a Prefix 0 with a billing increment of 30 seconds in location 0601 you enter on the telephone key pad **0601*0*30#**

Example #2: To store a Prefix 011573 with a billing increment of 60 seconds in location 0602, you enter from the telephone key pad **0602*011573*60#**

How to set default billing increment

If you cannot set billing increment for all route destinations, you can set a default billing increment that all route prefixes not configured in the unit can be used to compute cost.

To enter default billing increment enter the following **0600*duration#**

Where:

Duration = the billing increment used to compute cost, values range is 0 - 999

How to set billing cost per pulse

Press **0803*amount#**

Where:

Amount = the cost per pulse for all calls, the range of this value is 0 – 9999.

How to set service tax & service charge

Press **0804*percent# - for service tax** **0805*amount# - for service charge**

Where:

Percent = rate to computer tax, rate is based on percentage of cost, value range 0 – 9999

Amount = fixed amount to add to the cost of every call placed, value range 0 - 9999

